

Группа	Обозначение	Возможная замена	Применяется на																	
			4300B	4301	4302	4302A	4308	4308A	4309	4309A	4325	4326	4327	4340	4330	4331	4332	4333	4333A	4325Б
Прокладка	4330.00.04	4330.00.07												X	X	X	X	X		
	4301.00.13		X	X	X	X					X	X	X						X	
	4301.00.14		X	X	X	X					X	X	X						X	
	4308.00.13	4308.00.16					X	X	X	X				X						
	4308.00.14						X	X	X	X				X						
	4340.00.04		4340.00.05												X					
	4340.01.06														X					
	4327.00.07													X						X
	94.08A														X					
Втулка	4301.00.12		X	X	X	X					X	X	X						X	
	4308.00.12					X	X	X	X				X							
	4326.00.04	4326.00.05										X								
	4301.00.15	4301.00.20	X	X	X	X					X	X								
Ручка	4301.00.15-01	4301.00.20-01											X						X	
	4308.00.15	4308.00.20					X	X	X	X										
	4330.01.00													X	X	X				
	4330.01.00-01																X			
	4330.01.00-02																	X		
	4340.00.03	4340.20.00												X						
Наконечник	94.09A													X						
Кольцо	006-009-19-2-3													X	X	X	X	X		